

Easi-Detectors User Guide

(EL47411)


The TTS Easi-Detectors come in a set of 6 (each detector a different colour) with a rechargeable docking station for easy storage and charging.

They have been designed, not only to be metal detectors, but also have a magnifying glass (embedded in the ring of the detector) and bendable neck which encourages curiosity, independence, exploration and discovery of the natural world.

What is included in your pack

Each pack contains:

- Rechargeable docking station
- 6 Easi-Detectors each in a different colour (blue, yellow, pink, green, orange and purple)
- USB-C charging cable to be connected to the docking station



Charging the Easi-Detectors and switching them on


Before using the Easi-Detectors, make sure they are charged. Here is some charging information.

- To charge the Easi-Detectors, attach the USB-C cable to the docking station and plug in.
- The Easi-Detectors will take approximately 4 hours until fully charged.
- Once charged, they will last for approximately 6 hours.
- Start by turning the detector on by using the on/off switch on the handle. The light on the top of the handle will glow green to show they are ready to use.

Easi-Detectors User Guide





(EL47411)

There are 4 different settings to choose from. These are designed to cater for individual needs and preferences. Each setting can be chosen by turning the arrow on the dial to the relevant icon.



Different settings for the Easi-Detectors

Below is a table showing the 4 different settings and what each one does.

Icon	What will happen when you detect metal
	On this setting, the top of the handle will remain green until metal is detected. Once metal is detected, the handle will light up red and make a beeping sound.
	If the arrow is pointing to this icon, when metal is detected, the light on the handle will turn red and vibrate.
	For this setting, the handle will turn red when metal is found. There will be NO vibration or sound.
	On this setting, the handle will light up red, vibrate and will beep to show metal has been detected.

Enjoy exploring and see what treasures you can find!